



BEAMZ
MADE
EAZY

150.432 V1.1

COBRA 100R

QUICK START GUIDE

CONTROL MENU

MENU		DESCRIPTION
MX ADDR	A001-A512	DMX address setting 001-512
CHND	15CH	DMX channel
SLND	DMX/AUTO/SOUND	Running mode
REVERS PAN	Yes/ No	Reverse Pan
REVERS TILT	Yes/ No	Reverse Tilt
SENE	000-100	Sound sensitive
LED	On / Off	Black light
DISPLAY	Yes/ No	Display reverse
TEMP	XXX	Device's temperature
VER	V100	Software version
FAET	Yes/ No	Restore to factory set

DMX CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	Pan	000-255	
2	Pan Fine	000-255	
3	Tilt	000-255	
4	Tilt Fine	000-255	
5	P/T Speed	000-255	Speed from fast to slow
6	Dimmer	000-255	Dimmer from dark to brighter
7	Strobe	000	No Function
		001-255	Strobe from slow to fast
8	Color	001-015	Open
		016-031	Color 1
		032-047	Color 2
		048-063	Color 3
		064-079	Color 4
		080-095	Color 5
		096-111	Color 6
		112-127	Color 7
		128-191	Color Wheel clockwise rotate from fast to slow
		192-255	Color Wheel counter-clockwise rotate from slow to fast
9	Gobo	000-007	White
		008-015	Gobo 1
		016-023	Gobo 2
		024-031	Gobo 3
		032-039	Gobo 4
		040-047	Gobo 5
		048-055	Gobo 6
		056-063	Gobo 7
		064-073	Gobo 7 shake from slow to fast
		074-083	Gobo 6 shake from slow to fast
		084-093	Gobo 5 shake from slow to fast
		094-103	Gobo 4 shake from slow to fast
		104-113	Gobo 3 shake from slow to fast
		114-123	Gobo 2 shake from slow to fast
		124-127	Gobo 1 shake from slow to fast
		128-191	Gobo Wheel clockwise rotate from fast to slow
		192-255	Gobo Wheel counter-clockwise rotate from slow to fast
10	Prism	000-007	Prism off
		008-127	Prism on
		128-255	Prism rotate from slow to fast
11	LED Ring Macro Function	000-007	Prism off
		008-127	Prism on
		128-255	Prism rotate from slow to fast
12	Self-Edit Effect	000-007	OFF
	Running Color	008-025	Red
		026-043	Green
		044-061	Blue
		062-079	Red+Green
		080-097	Red+Blue
		098-115	Green+Blue
		116-127	Red+Green+Blue
128-140	Built-in Effect 1 from slow to fast		

		141-153	Built-in Effect 2 from slow to fast
		154-165	Self-Edit effect 1(Editable) from slow to fast
		166-178	Self-Edit effect 2 (Editable) from slow to fast
		179-191	Self-Edit effect 3 (Editable) from slow to fast
		192-204	Self-Edit effect 4 (Editable) from slow to fast
		205-217	Self-Edit effect 5 (Editable) from slow to fast
		218-230	Self-Edit effect 6 (Editable) from slow to fast
		231-243	Self-Edit effect 7 (Editable) from slow to fast
		245-255	Self-Edit effect 8 (Editable) from slow to fast
13	Self-Edit Effect Background Color	000-007	OFF
		008-025	Red(from dark to brighter)
		026-043	Green(from dark to brighter)
		044-051	Blue(from dark to brighter)
		052-069	Red+Green(from dark to brighter)
		070-087	Red+Blue(from dark to brighter)
		088-105	Green+Blue(from dark to brighter)
		106-255	Red+Green+Blue(from dark to brighter)
14	Macro Function	000-049	CH1-CH13 valid
		050-200	Auto Running
		201-255	Sound Control
15	Reset	000-240	No function
		241-255	All reset after 5s

*In DMX Mode, If there is no DMX Signal, the first digital will flash, when the display is off, the middle position of last digital will flash.
In MENU-TEMP, When it shows ERR, It means temperature control not being installed or short circuit.



A series of horizontal dotted lines for writing, spanning the width of the page.



A series of horizontal dotted lines for writing, spanning the width of the page.





A series of horizontal dotted lines for writing, spanning the width of the page.



BEAMZ

**YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT**



is a leading developer of lighting products, including intelligent DMX moving heads, wireless battery operated DMX effects, static washes, sound-activated club effects, strobes & blacklights, LED lighting, fog and special effects machines, lasers and indoor and outdoor architectural lighting, as well as lighting controllers and protective bags.

