



155.105 V1.0

BTK200W QUICK START GUIDE

CONTROL MENU

MENU		DESCRIPTION	
DMX-ADDR 001	001-512	Press up or down to set DMX address, press Enter to save	
L-DIMMER 000	000-255	Dimming from darkness to brightness, press Enter to save	
P-STROBE 000	000-255	Strobe from slow to fast, press Enter to save	
DMX-KEEP	OFF	In case of lost DMX signal, turn to black out mode, press Enter to save	
OFF	ON	In case of lost DMX signal, keep last DMX setting, press Enter to save	
BK-LIGHT	OFF	Display on , press Enter to save	
ON	ON	Display off if no operating, press Enter to save	
NOW TEMP XX°C		Show current temperature	

DMX CHANNELS

CHANNEL	FUNCTION	VALUE	DESCRIPTION
1	DIMMER	000-255	Dimming setting
2	STROBE SPEED	000-128	Strobe from slow to fast
		129-255	Strobe from fast to slow

YOUR FUTURE YOUR SKILLS YOUR PLATFORM YOUR PARTY YOUR EVENT

≥beamZ^{Pro}

offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!