




BEAMZ
MADE
EAZY

151.534 V1.0

NEUTRON-ATOM
QUICK START GUIDE

CONTROL MENU


If the display is in standby, unlock it



MENU	DESCRIPTION		
MODE	DMX ADDR	A001-A512	DMX address setting
	DMX MODE	6CH 8CH 14CH 21CH 24CH 112CH 127CH	DMX channel mode
	SLAVE		Slave mode
	AUTO	01-31	Auto program
STATIC		000-255	Auto Speed
		000-255	Beam Dimmer
		000-255	Beam strobe duration
		000-255	Beam strobe
		000-255	Aura strobe duration
		000-255	Aura strobe
		000-255	Beam Red
		000-255	Beam Green
		000-255	Beam Blue
		000-255	Beam Amber
		000-255	Beam Lime
		000-255	Colour macro
		000-255	Aura Red
		000-255	Aura Green
		000-255	Aura Blue
	SETTINGS	DISPLAY REV	On/Off
DISPLAY		On/Off	Display on/off option
DMX FAIL		Freeze	When no dmx
		Blackout	
		Auto	
DIMMER CURVE		Linear	Dimmer Curve
		Exp	
		Square	
		S-Curve	
DIMMER RESPONSE			Led
		Halogen	
LED FREQUENCY		800Hz	
		1200Hz	
		2000Hz	
		3600Hz	
		6000Hz	
		15KHz	
TEST	On/Off	Function test	
FACTORY RESET	Reset now?	Yes	
AUTO LOCK	No Lock	Display lock	
	60 Seconds		
LANGUAGE		English	

			Chinese
SYSTEM INFO	FIRMWARE	Software Ver.	Vxxxx
	ERROR INFO	Led Sensor	Error/OK
TEMPERATURE	Temp		xx°C
	Temp Unit		Fahrenheit
			Celsius
TIME INFO	Power On		XXXHours
	Last Run Hrs		XXXHours

DIMMING CURVES



DMX CHANNELS

6 CHANNELS

CHANNELS	FUNCTION	VALUE	DESCRIPTION
1	MASTER DIMMER	000-255	Master Dimmer 0-100%
2	STROBE	000-005	Strobe open
		006-010	Strobe closed
		011-250	Strobe from slow to fast
		251-255	Strobe open
3	COLOUR MACRO	000-005	No Function
		006-012	Red
		013-019	Amber
		020-026	Yellow Amber
		027-033	Yellow
		034-040	Green
		041-047	Turquoise
		048-054	Cyan
		055-061	Blue
		062-068	Lavender
		069-075	Mauve
		076-082	Magenta
		083-089	Pink
		090-096	White 1
		097-103	White 2
		104-110	White 3
		111-117	White 4
118-124	White 5		
125-127	Colour jump stop		
128-191	Colour jump from slow to fast		
192-255	Colour fading from slow to fast		
4	AURA RED	000-255	Aura Dimmer Red 0-100%
5	AURA GREEN	000-255	Aura Dimmer Green 0-100%
6	AURA BLUE	000-255	Aura Dimmer Blue 0-100%

8 CHANNELS

CHANNELS	FUNCTION	VALUE	DESCRIPTION
1	RED	000-255	Dimmer Red 0-100%
2	GREEN	000-255	Dimmer Green 0-100%
3	BLUE	000-255	Dimmer Blue 0-100%
4	AMBER	000-255	Dimmer Amber 0-100%
5	LIME	000-255	Dimmer Lime 0-100%
6	AURA RED	000-255	Aura Dimmer Red 0-100%
7	AURA GREEN	000-255	Aura Dimmer Green 0-100%
8	AURA BLUE	000-255	Aura Dimmer Blue 0-100%

14 CHANNELS

CHANNELS	FUNCTION	VALUE	DESCRIPTION
1	MASTER DIMMER	000-255	Master Dimmer 0-100%
2	BEAM STROBE DURATION	000-005	Strobe open
		006-250	Strobe duration from slow to fast
		251-255	Strobe open
3	BEAM STROBE	000-005	Strobe open
		006-010	Strobe closed
		011-250	Strobe from slow to fast
		251-255	Strobe open
4	AURA STROBE DURATION	000-005	Strobe open
		006-250	Strobe duration from slow to fast
		251-255	Strobe open
5	AURA STROBE	000-005	Strobe open
		006-010	Strobe closed
		006-250	Strobe from slow to fast
		251-255	Strobe open
6	RED	000-255	Dimmer Red 0-100%
7	GREEN	000-255	Dimmer Green 0-100%
8	BLUE	000-255	Dimmer Blue 0-100%
9	AMBER	000-255	Dimmer Amber 0-100%
10	LIME	000-255	Dimmer Lime 0-100%
11	COLOUR MACRO	000-005	No Function
		006-012	Red
		013-019	Amber
		020-026	Yellow Amber
		027-033	Yellow
		034-040	Green
		041-047	Turquoise
		048-054	Cyan
		055-061	Blue
		062-068	Lavender
		069-075	Mauve
		076-082	Magenta
		083-089	Pink
		090-096	White 1
		097-103	White 2
104-110	White 3		
111-117	White 4		
118-124	White 5		
125-127	Colour jump stop		
128-191	Colour jump from slow to fast		

		192-255	Colour fading from slow to fast
12	AURA RED	000-255	Aura Dimmer Red 0-100%
13	AURA GREEN	000-255	Aura Dimmer Green 0-100%
14	AURA BLUE	000-255	Aura Dimmer Blue 0-100%

21 CHANNELS

CHANNELS	FUNCTION	VALUE	DESCRIPTION
1	BEAM DIMMER	000-255	Beam Master Dimmer 0-100%
2	BEAM DIMMER FINE	000-255	Beam Dimmer Fine 0-100%
3	AURA DIMMER	000-255	Aura Dimmer 0-100%
4	AURA DIMMER FINE	000-255	Aura Dimmer Fine 0-100%
5	BEAM STROBE DURATION	000-005	Strobe open
		006-250	Strobe duration from slow to fast
		251-255	Strobe open
6	BEAM STROBE	000-005	Strobe open
		006-010	Strobe closed
		011-022	Ramp up/down from slow to fast
		023-033	Ramp up/down random from slow to fast
		034-045	Ramp up from slow to fast
		046-056	Ramp up random from slow to fast
		057-068	Ramp down from slow to fast
		069-079	Ramp down random from slow to fast
		080-102	Random strobe effect from slow to fast
		103-127	Strobe break
		128-250	Strobe from slow to fast
7	AURA STROBE DURATION	251-255	Strobe open
		000-005	Strobe open
		006-250	Strobe duration from slow to fast
8	AURA STROBE	251-255	Strobe open
		000-005	Strobe open
		006-010	Strobe closed
		011-022	Ramp up/down from slow to fast
		023-033	Ramp up/down random from slow to fast
		034-045	Ramp up from slow to fast
		046-056	Ramp up random from slow to fast
		057-068	Ramp down from slow to fast
		069-079	Ramp down random from slow to fast
		080-102	Random strobe effect from slow to fast
		103-127	Strobe break
128-250	Strobe from slow to fast		
9	RED	000-255	Dimmer Red 0-100%
10	GREEN	000-255	Dimmer Green 0-100%
11	BLUE	000-255	Dimmer Blue 0-100%
12	AMBER	000-255	Dimmer Amber 0-100%
13	LIME	000-255	Dimmer Lime 0-100%
14	COLOUR MACRO	000-005	No Function
		006-012	Red
		013-019	Amber
		020-026	Yellow Amber
		027-033	Yellow
		034-040	Green
		041-047	Turquoise

		048-054	Cyan
		055-061	Blue
		062-068	Lavender
		069-075	Mauve
		076-082	Magenta
		083-089	Pink
		090-096	White 1
		097-103	White 2
		104-110	White 3
		111-117	White 4
		118-124	White 5
		125-127	Colour jump stop
		128-191	Colour jump from slow to fast
		192-255	Colour fading from slow to fast
15	AURA RED	000-255	Aura Dimmer Red 0-100%
16	AURA GREEN	000-255	Aura Dimmer Green 0-100%
17	AURA BLUE	000-255	Aura Dimmer Blue 0-100%
18	AURA COLOUR MACRO	000-010	No Function
		011-011	Red:0 Green:0 Blue:255
		012-048	Red:0 Green:+ Blue:255
		049-049	Red:0 Green:255 Blue:255
		050-086	Red:0 Green:255 Blue:-
		087-087	Red:0 Green:255 Blue:0
		088-124	Red:+ Green:255 Blue 0
		125-125	Red:255 Green:255 Blue:0
		126-162	Red:255 Green:- Blue:0
		163-163	Red:255 Green:0 Blue:0
		164-200	Red:255 Green:0 Blue:+
		201-201	Red:255 Green:0 Blue:255
		202-238	Red:- Green:0 Blue:255
		239-239	Red:0 Green:0 Blue:255
		240-247	Colour rotation from fast to slow
		248-255	Colour snap from fast to slow
19	AURA EFFECT	000-005	No Function
		006-008	Effect 1
		009-011	Effect 2
		012-014	Effect 3
	
		240-242	Effect 79
		243-245	Effect 80
		246-248	Effect 81
		249-255	No Function
20	SPEED	000-255	Effect speed from slow to fast
21	SETTINGS	000-005	No Function
		006-015	Display on
		016-025	Display off
		026-035	No Function
		036-045	Dimmer Curve Linear
		046-055	Dimmer Curve Square
		056-065	Dimmer Curve invert Square
		066-075	Dimmer Curve S-Curve
		076-085	No Function

086-095	Dimmer speed mode
096-105	Dimmer speed halogen
106-115	No Function
116-125	Led Freq. 800Hz
126-135	Led Freq. 1200Hz
136-145	Led Freq. 2000Hz
146-155	Led Freq. 3600Hz
156-165	Led Freq. 6000Hz
166-175	Led Freq. 25KHz
176-255	No Function

24 CHANNELS

CHANNELS	FUNCTION	VALUE	DESCRIPTION
1	BEAM DIMMER	000-255	Beam Master Dimmer 0-100%
2	BEAM DIMMER FINE	000-255	Beam Dimmer Fine 0-100%
3	AURA DIMMER	000-255	Aura Dimmer 0-100%
4	AURA DIMMER FINE	000-255	Aura Dimmer Fine 0-100%
5	BEAM STROBE DURATION	000-005	Strobe open
		006-250	Strobe duration from slow to fast
		251-255	Strobe open
6	BEAM STROBE	000-005	Strobe open
		006-010	Strobe closed
		011-022	Ramp up/down from slow to fast
		023-033	Ramp up/down random from slow to fast
		034-045	Ramp up from slow to fast
		046-056	Ramp up random from slow to fast
		057-068	Ramp down from slow to fast
		069-079	Ramp down random from slow to fast
		080-102	Random strobe effect from slow to fast
		103-127	Strobe break
		128-250	Strobe from slow to fast
		251-255	Strobe open
		7	AURA STROBE DURATION
006-250	Strobe duration from slow to fast		
251-255	Strobe open		
8	AURA STROBE	000-005	Strobe open
		006-010	Strobe closed
		011-022	Ramp up/down from slow to fast
		023-033	Ramp up/down random from slow to fast
		034-045	Ramp up from slow to fast
		046-056	Ramp up random from slow to fast
		057-068	Ramp down from slow to fast
		069-079	Ramp down random from slow to fast
		080-102	Random strobe effect from slow to fast
		103-127	Strobe break
		128-250	Strobe from slow to fast
		251-255	Strobe open
		9	RED
10	GREEN	000-255	Dimmer Green 0-100%
11	BLUE	000-255	Dimmer Blue 0-100%
12	AMBER	000-255	Dimmer Amber 0-100%
13	LIME	000-255	Dimmer Lime 0-100%
14	COLOUR MACRO	000-005	No Function

		006-012	Red
		013-019	Amber
		020-026	Yellow Amber
		027-033	Yellow
		034-040	Green
		041-047	Turquoise
		048-054	Cyan
		055-061	Blue
		062-068	Lavender
		069-075	Mauve
		076-082	Magenta
		083-089	Pink
		090-096	White 1
		097-103	White 2
		104-110	White 3
		111-117	White 4
		118-124	White 5
		125-127	Colour jump stop
		128-191	Colour jump from slow to fast
		192-255	Colour fading from slow to fast
15	AURA RED	000-255	Aura Dimmer Red 0-100%
16	AURA GREEN	000-255	Aura Dimmer Green 0-100%
17	AURA BLUE	000-255	Aura Dimmer Blue 0-100%
18	AURA FOREGROUND COLOUR MACRO	000-010	No Function
		011-011	Red:0 Green:0 Blue:255
		012-048	Red:0 Green:+ Blue:255
		049-049	Red:0 Green:255 Blue:255
		050-086	Red:0 Green:255 Blue:-
		087-087	Red:0 Green:255 Blue:0
		088-124	Red:+ Green:255 Blue 0
		125-125	Red:255 Green:255 Blue:0
		126-162	Red:255 Green:- Blue:0
		163-163	Red:255 Green:0 Blue:0
		164-200	Red:255 Green:0 Blue:+
		201-201	Red:255 Green:0 Blue:255
		202-238	Red:- Green:0 Blue:255
		239-239	Red:0 Green:0 Blue:255
		240-247	Colour rotation from fast to slow
		248-255	Colour snap from fast to slow
19	AURA FOREGROUND DIMMER	000-255	Aura Foreground Dimmer 0-100%
20	AURA BACKGROUND COLOUR MACRO	000-010	No Function
		011-011	Red:0 Green:0 Blue:255
		012-048	Red:0 Green:+ Blue:255
		049-049	Red:0 Green:255 Blue:255
		050-086	Red:0 Green:255 Blue:-
		087-087	Red:0 Green:255 Blue:0
		088-124	Red:+ Green:255 Blue 0
		125-125	Red:255 Green:255 Blue:0
		126-162	Red:255 Green:- Blue:0
		163-163	Red:255 Green:0 Blue:0
		164-200	Red:255 Green:0 Blue:+

		201-201	Red:255 Green:0 Blue:255
		202-238	Red:- Green:0 Blue:255
		239-239	Red:0 Green:0 Blue:255
		240-247	Colour rotation from fast to slow
		248-255	Colour snap from fast to slow
21	AURA BACKGROUND DIMMER	000-255	Aura Background Dimmer 0-100%
22	AURA EFFECT	000-005	No Function
		006-008	Effect 1
		009-011	Effect 2
		012-014	Effect 3
	
		240-242	Effect 79
		243-245	Effect 80
		246-248	Effect 81
		249-255	No Function
23	SPEED	000-255	Effect speed from slow to fast
24	SETTINGS	000-005	No Function
		006-015	Display on
		016-025	Display off
		026-035	No Function
		036-045	Dimmer Curve Linear
		046-055	Dimmer Curve Square
		056-065	Dimmer Curve invert Square
		066-075	Dimmer Curve S-Curve
		076-085	No Function
		086-095	Dimmer speed mode
		096-105	Dimmer speed halogen
		106-115	No Function
		116-125	Led Freq. 800Hz
		126-135	Led Freq. 1200Hz
		136-145	Led Freq. 2000Hz
		146-155	Led Freq. 3600Hz
		156-165	Led Freq. 6000Hz
		166-175	Led Freq. 25KHz
		176-255	No Function

115 CHANNELS

CHANNELS	FUNCTION	VALUE	DESCRIPTION
1	MASTER DIMMER	000-255	Master Dimmer 0-100%
2	STROBE	000-005	Strobe open
		006-010	Strobe closed
		011-250	Strobe from slow to fast
		251-255	Strobe open
3	RED	000-255	Dimmer Red 0-100%
4	GREEN	000-255	Dimmer Green 0-100%
5	BLUE	000-255	Dimmer Blue 0-100%
6	AMBER	000-255	Dimmer Amber 0-100%
7	LIME	000-255	Dimmer Lime 0-100%
8	AURA RED	000-255	Segment 1 Aura Dimmer Red 0-100%
9	AURA GREEN	000-255	Segment 1 Aura Dimmer Green 0-100%
10	AURA BLUE	000-255	Segment 1 Aura Dimmer Blue 0-100%
.....

113	AURA RED	000-255	Segment 36 Aura Dimmer Red 0-100%
114	AURA GREEN	000-255	Segment 36 Aura Dimmer Green 0-100%
115	AURA BLUE	000-255	Segment 36 Aura Dimmer Blue 0-100%

127 CHANNELS

CHANNELS	FUNCTION	VALUE	DESCRIPTION
1	MASTER DIMMER	000-255	Master Dimmer 0-100%
2	BEAM DIMMER	000-255	Beam Dimmer 0-100%
3	AURA DIMMER	000-255	Aura Dimmer 0-100%
4	BEAM STROBE DURATION	000-005	Strobe open
		006-250	Strobe duration from slow to fast
		251-255	Strobe open
5	BEAM STROBE	000-005	Strobe open
		006-010	Strobe closed
		011-022	Ramp up/down from slow to fast
		023-033	Ramp up/down random from slow to fast
		034-045	Ramp up from slow to fast
		046-056	Ramp up random from slow to fast
		057-068	Ramp down from slow to fast
		069-079	Ramp down random from slow to fast
		080-102	Random strobe effect from slow to fast
		103-127	Strobe break
		128-250	Strobe from slow to fast
6	AURA STROBE DURATION	000-005	Strobe open
		006-250	Strobe duration from slow to fast
		251-255	Strobe open
7	AURA STROBE	000-005	Strobe open
		006-010	Strobe closed
		011-022	Ramp up/down from slow to fast
		023-033	Ramp up/down random from slow to fast
		034-045	Ramp up from slow to fast
		046-056	Ramp up random from slow to fast
		057-068	Ramp down from slow to fast
		069-079	Ramp down random from slow to fast
		080-102	Random strobe effect from slow to fast
		103-127	Strobe break
		128-250	Strobe from slow to fast
9	RED	000-255	Dimmer Red 0-100%
		000-255	Dimmer Green 0-100%
		000-255	Dimmer Blue 0-100%
10	GREEN	000-255	Dimmer Green 0-100%
11	BLUE	000-255	Dimmer Blue 0-100%
12	AMBER	000-255	Dimmer Amber 0-100%
13	LIME	000-255	Dimmer Lime 0-100%
14	AURA RED	000-255	Segment 1 Aura Dimmer Red 0-100%
15	AURA GREEN	000-255	Segment 1 Aura Dimmer Green 0-100%
16	AURA BLUE	000-255	Segment 1 Aura Dimmer Blue 0-100%
.....
118	AURA RED	000-255	Segment 36 Aura Dimmer Red 0-100%
119	AURA GREEN	000-255	Segment 36 Aura Dimmer Green 0-100%
120	AURA BLUE	000-255	Segment 36 Aura Dimmer Blue 0-100%
121	AURA	000-010	No Function
		011-011	Red:0 Green:0 Blue:255

	FOREGROUND COLOUR MACRO	012-048	Red:0 Green:+ Blue:255
		049-049	Red:0 Green:255 Blue:255
		050-086	Red:0 Green:255 Blue:-
		087-087	Red:0 Green:255 Blue:0
121	AURA FOREGROUND COLOUR MACRO	088-124	Red:+ Green:255 Blue 0
		125-125	Red:255 Green:255 Blue:0
		126-162	Red:255 Green:- Blue:0
		163-163	Red:255 Green:0 Blue:0
		164-200	Red:255 Green:0 Blue:+
		201-201	Red:255 Green:0 Blue:255
		202-238	Red:- Green:0 Blue:255
		239-239	Red:0 Green:0 Blue:255
		240-247	Colour rotation from fast to slow
		248-255	Colour snap from fast to slow
122	AURA FOREGROUND DIMMER	000-255	Aura Foreground Dimmer 0-100%
123	AURA BACKGROUND COLOUR MACRO	000-010	No Function
		011-011	Red:0 Green:0 Blue:255
		012-048	Red:0 Green:+ Blue:255
		049-049	Red:0 Green:255 Blue:255
		050-086	Red:0 Green:255 Blue:-
		087-087	Red:0 Green:255 Blue:0
		088-124	Red:+ Green:255 Blue 0
		125-125	Red:255 Green:255 Blue:0
		126-162	Red:255 Green:- Blue:0
		163-163	Red:255 Green:0 Blue:0
		164-200	Red:255 Green:0 Blue:+
		201-201	Red:255 Green:0 Blue:255
		202-238	Red:- Green:0 Blue:255
		239-239	Red:0 Green:0 Blue:255
		240-247	Colour rotation from fast to slow
		248-255	Colour snap from fast to slow
124	AURA BACKGROUND DIMMER	000-255	Aura Background Dimmer 0-100%
125	AURA EFFECT	000-005	No Function
		006-008	Effect 1
		009-011	Effect 2
		012-014	Effect 3
	
		240-242	Effect 79
		243-245	Effect 80
		246-248	Effect 81
126	SPEED	000-255	Effect speed from slow to fast
127	SETTINGS	000-005	No Function
		006-015	Display on
		016-025	Display off
		026-035	No Function
		036-045	Dimmer Curve Linear
		046-055	Dimmer Curve Square
		056-065	Dimmer Curve invert Square
		066-075	Dimmer Curve S-Curve
		076-085	No Function



		086-095	Dimmer speed mode
		096-105	Dimmer speed halogen
		106-115	No Function
127	SETTINGS	116-125	Led Freq. 800Hz
		126-135	Led Freq. 1200Hz
		136-145	Led Freq. 2000Hz
		146-155	Led Freq. 3600Hz
		156-165	Led Freq. 6000Hz
		166-175	Led Freq. 25KHz
		176-255	No Function









BEAMZ

YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT



offers a wide range of high performance lighting equipment and related accessories for the rental, entertainment and architectural lighting markets. BeamZ Pro stands for performance, innovation and value pricing!

